2050-50

INSTALLATION GUIDE



1. Unlatch the lid and remove the lid from the body of the valve. The media canister is wrapped in plastic for delivery. Remove the wrapped media canister by lifting up on the handles provided on the media canister.



3. Reinstall media canisters ensuring they are flush with the valve's inner chamber.



2. Ensure all of the original plastic wrap is removed from canister before reinstalling. Media is in pellet form and should move freely to allow air to vent through. To check the media, pull up on the blue tab on the media canister lid. Check that the media pellets are dry.



4. Secure the lid with the four lockable latches. Place the unit slightly above the air release valve upon installation. This will allow excessive moisture to drain back into the ARV.



www.wagerusa.com 336.9696909 LWager@wagerusa.com Mpowers@wagerusa.com

* 2050-50 Side Access Shown