

# 2050-450-IP

## INSTALLATION GUIDE



1. Remove media canisters. Ensure all of the original plastic wrap is removed from canisters. Media is in pellet form and should move freely to allow air to vent through. Check media pellets to ensure they are NOT wet.



2. Reinstall media canisters ensuring they are flush with the valve's inner chamber.



3. Place unit in desire location. Bolt flange to vent stack.



4. Secure the lid with the four lockable latches



**WAGER**  
C O M P A N Y

**\* 2050-450 PICTURED. MODEL 2050-450-IP FOLLOWS THE SAME STEPS.**

[www.wagerusa.com](http://www.wagerusa.com)  
336.9696909  
[LWager@wagerusa.com](mailto:LWager@wagerusa.com)  
[Mpowers@wagerusa.com](mailto:Mpowers@wagerusa.com)