

Tank Air Escape Valves allow free passage of air into tanks, dry cargo holds, or storage space. They protect tanks and bulkheads from pressure build-up during loading and unloading of liquid or dry cargo and assure maximum efficiency during operations.

Tank air escape valves do not have a float or automatic closing, they are used in locations not accessible to sea water.

All steel castings are hot dipped galvanized. All aluminum castings are anodized.




BODY



**FLAME
SCREEN**



**SPACER
RING**



**PROTECTIVE
MESH**



CAP

SPECIFICATIONS

GALVANIZED STEEL

CONNECTIONS:

- THREADED
- BUTTWELD
- SOCKETWELD
- FLANGED (METRIC AVAILABLE)

SIZES:

- 1.5", 2", 2.5", 3", 4", 5", 6", 8", 10", 12", 14", 16"

BRONZE

CONNECTIONS:

- THREADED
- SIL-BRAZED
- FLANGED

SIZES:

- 1.5", 2", 2.5", 3", 4", 5", 6", 8", 10", 12"

ANODIZED ALUMINUM

CONNECTIONS:

- THREADED
- BUTTWELD
- SOCKETWELD
- FLANGED (METRIC AVAILABLE)

SIZES:

- 1.5", 2", 2.5", 3", 4", 5", 6", 8", 10", 12"

STAINLESS STEEL

CONNECTIONS:

- THREADED
- BUTTWELD
- SOCKETWELD
- FLANGED (METRIC AVAILABLE)

SIZES:

- 1.5", 2", 2.5", 3", 4", 5", 6", 8", 10", 12", 14", 16"